PartyPod: Bluetooth Speaker with LED Lightshow

100.619UK

User Manual

Take the party with you, with cutting edge features, LED light show and powerful sound. Offering the latest Bluetooth connectivity for ultimate device compatibility, the QTX PartyPod can go anywhere due to its waterproof design, handy carry strap and up to 6 hours playback from a single charge. Inbuilt FM radio, USB and TF/Micro SD slots add to its versatility, enabling direct playback of MP3 files from compatible media. Connect to a 2nd unit using the TWS function to enhance your sound experience to true wireless stereo.

- Stylish and rugged design with IPX4 splash resistance.
- Connect to your smart device via Bluetooth.
- Dual LED colour light show effect in front grille.
- Direct MP3 playback via inbuilt USB and Micro SD ports.
- Twin speaker design delivers deep bass and clear, crisp treble.
- Inbuilt FM radio and microphone for hands-free phone calls.
- True wireless stereo (TWS) function for connection to a second unit.
- Internal rechargeable battery with up to 6 hours playback.

Technical Specifications:

Audio output	2x 8W
Speaker drivers	2 x 52mm
Frequency response	20Hz-16KHz
Bluetooth version	5.0
Battery type	3.7V 2400mA internal rechargeable lithium ion
Battery life	Up to 6 hours
Charge time	Up to 4 hours (from flat)
IP Rating	IPX4
Input connections	Bluetooth, USB, Micro SD (TF Card), USB Type-C (DC 5V/2A - charge only)
Power input	DC 5V/2A
Dimensions	240 x 94 x 94mm
Weight	840g

Controls Overview:

1.   Power button:
Long press to turn the speaker on and off and short press to change the input mode between Bluetooth and FM tuner. When in Bluetooth mode the LED indicator (**9**) on the speaker with flash blue, to pair with your device activate Bluetooth on your smartphone or tablet then select "**QTX - PartyPod"** from the device list. Once paired successfully, a connecting tone will be heard and the LED indicator (**9**) on the unit will light solid blue. The speaker will remember your Bluetooth device and connect automatically if the two devices are within range and your smart device is set as 'discoverable'.

2. Previous track/lower volume button:
Short press to lower the master volume and long press to go back to the previous track in your playlist.

3. Next track/increase volume button:
Short press to increase the master volume or long press to go to the next track in your playlist.

4. Play/pause button:
Short press to play or pause the current track or to answer an incoming phone call in Bluetooth mode, double press to redial the last logged number and long press to reject an incoming call. In FM mode, long press to perform a channel scan and short press to select the current station. To pair and unpair with another speaker using the TWS function press and hold the Play/pause button on one unit for around 3 seconds until a short tone is heard, with both speakers turned on and the other speaker already connected to your Bluetooth device.

5. LED lightshow button:
Press repeatedly to scroll between 7 available lightshow modes or to turn the lightshow off (mode 8).

6. USB port:
The speaker is compatible with USB storage devices and can play MP3 audio files directly. Simply insert a compatible drive into the slot and the unit will automatically switch to USB mode and play the first compatible track. You can also use the media controls on the unit to play, pause and navigate between tracks on the drive.

7. TF card slot:
The speaker is also compatible with TF/MicroSD cards of up to 64GB in size and can play MP3 audio files directly. Simply insert a compatible card into the slot and the unit will automatically switch to TF mode and play the first compatible track. You can use the media controls on the front of the unit to play, pause and navigate between tracks on the card.

8. USB Type-C charging port:
Connect using the USB charging lead provided to a compatible power source (DC5V/2A) for powering and charging the device. A full charge can take anything up to 4 hours. **NB: we recommend that you only use the USB cable provided when charging the speaker.**

9. LED Indicator:
Displays a solid red light during charging, which goes out when the unit is charged; Flashing blue light in Bluetooth pairing mode; Solid blue light when paired to a compatible device and rapid flashing blue light in USB and TF modes.

In the box:

1. Bluetooth speaker   2. USB charging lead   3. User manual

FAQ

Q) Why won't my Bluetooth device connect to the speaker? **A)** The speaker may not be in pairing mode, or the Bluetooth device may not be set as 'discoverable'. Check these settings, then try again.

Q) Why does the speaker disconnect from my Bluetooth device within the stated 10m transmission distance? **A)** Large metallic objects or other devices transmitting radio or wireless signals can impact on the reception of the speaker. To attain the maximum transmission distance, ensure there is a clear line of sight between the speaker and the Bluetooth device.

Q) Why won't the speaker switch on? **A)** The speaker may not be sufficiently charged. To recharge, connect the speaker to a USB port using the cable provided.

Q) Why won't the speaker play the files from my media? **A)** Please ensure any inserted media is formatted in FAT32 and any music files are in MP3 format.

Safety Disclaimer
Do not attempt to service this product yourself as opening or removing covers may result in fire, electric shock or equipment damage and will also invalidate the warranty. This product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.

CE $\overset{\text{UK}}{\text{CA}}$ ⊠ IPX4

This product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.