



## Paper-thin Transparent HDTV Aerial

Order ref: 120.515UK

User Manual

A lightweight, paper-thin aerial ideal to be fixed to a window or an outside facing wall, capable of receiving Digital Terrestrial TV and DAB/FM radio signals. The easy to conceal, transparent design means the aerial won't restrict your view. It comes with an extra-long 3m RF (Coaxial) lead, meaning you can position it in the area with the best reception in your home.

### Specification:


<b>Gain</b>	6-8dB
<b>Frequency range</b>	VHF: 47-230MHz, UHF: 470-694MHz (5G)
<b>Reception distance</b>	Up to 45 miles
<b>Impedance</b>	75Ω
<b>Dimensions</b>	228 x 128 x 0.5mm
<b>Weight</b>	60g

### Features:


- Lightweight, paper-thin aerial that can be fixed either to a window or an outside facing wall.
- Compatible with Digital Terrestrial TV and DAB/FM radio signals within a 35-45 mile radius.
- Integrated LTE signal filter avoids interference from 4G/5G mobile signals.
- Easy to conceal, transparent design.
- Supplied with extra-long 3m RF (Coaxial) lead, self-adhesive pad and window suckers.

### Connection and operation:

[Fig.1] Directly connected to TV



[Fig.2] Directly connected to terrestrial set-top box



1. Connect the aerial lead either directly to the back of your Digital TV [Fig.1] or Terrestrial STB [Fig.2] as shown in the diagrams above.
2. Next position the aerial in your desired location using either the self-adhesive pad or window suckers supplied.
3. For the best reception try and position as high as possible on an outside facing wall or window, away from large power consuming devices such as air-conditioning units, elevators, microwave ovens, hair dryers etc.
4. Finally run the channel scan operation on your TV or STB Setup and once complete test the quality of the channels. It may be necessary to reposition the aerial and try again if the signal quality is low or you are receiving interference or missing channels.

### Safety warnings:

- Do not use this appliance if it is damaged in any way.
- Do not attempt to repair this appliance or take apart under any circumstances, as this will invalidate your warranty.
- Do not use this appliance for anything other than its intended purpose, and do not use outdoors.
- Use only a damp cloth to clean the surface of the appliance and never attempt to clean while it is on or still hot.
- Please ensure you have read these instructions thoroughly before first use and keep them for future reference.



This product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.

### Errors and omissions excepted.

Copyright© 2024 AVSL Group Ltd, Unit 2 Bridgewater Park,  
Taylor Road, Trafford Park, Manchester. M41 7JQ.

AVSL (Europe) Ltd, Unit 3D North Point House,  
North Point Bus. Park, New Mallow Road, Cork, Ireland.