



KEYSWITCH SPARES

EXIT
BUTTONS



KS1-KEY

Pair of Replacement/Spare Keys
For use with the following:

KS-1
KS1-CO
JMB/KS-1
WP-VPKS-1
DU-KS/1
J/KS1-F
EXT/AP/KS-1
AP/KS-1
G-KS-1
W-KS-1



KS2-KEY

Pair of Replacement/Spare Keys
For use with the following:

KS-2
JMB/KS-2
WP-VPKS-2
DU-KS/2
J/KS2-BL-F
EXT/AP/KS2-BLANK
AP/KS-2BL



KS3-KEY

Pair of Replacement/Spare Keys
For use with the following:

KS-3
KS-3MOM
KS3CO-L
JMB/KS-3
JMB/KS-4
J/KS3-F
EXT/AP/KS-3
AP/KS-3
KS-FVE-3



KSA126-KEY

Pair of Replacement/Spare Keys
For use with the following:

KS-CP-S
KS-CP-D
KS-EDR-S
KS-EDR-D
KS1-DPDT
G-KS1-A126
KS-B-D
KS-B-S
KS-O-D
KS-O-S

OTHER PRODUCTS

WP-VPKS-1



KS-1



JMB/KS-3



KS-CP-S



Manufactured by a BSIA Member