



PENDANT Mk4 PEN4RC (Inhibit motion sensor shoe)



Using the Pendant (PEN4) with the Storage Shoe (PEN4RC)

The Pendant storage shoe (PEN4RC) is designed to inhibit the motion sensor and store the pendant when not in use.

With the motion sensor enabled, place the pendant in the shoe, the red light will come on for about 4s then flash red rapidly 3 times, indicating that the motion sensor is now disabled.

Note: the pendant must remain in the shoe for at least 30s for this function to operate correctly.

Removing the pendant from the shoe after this period will enable the motion sensor automatically, indicated by the light rapidly flashing green 3 times and then red once when the message is transmitted.

Note: If the pendant is removed within the 30s-time frame, or if it is misaligned when trying to insert or remove the unit then it can become out of sync. If this happens keep replacing the pendant in the shoe until the indicator lights red for about 4s then flashes red rapidly 3 times. This should only take up to two goes to achieve. Then leave for at least 30s before removing.

Remember – Flashing GREEN = motion sensor ON.

Scope offers free training at our manufacturing site in Devon on all our Scope products. If you would like to see the operation/capability of the complete Scope range for Fire, Lockdown, DDA, SOS, lone worker (with location), wireless link for fire panels (conform to BS5839-1:2017 (24.2b) and BSEN54-25:2008 (4.2.6) and more applications, please contact us to discuss available dates. If you would like any additional information, please refer to our Datasheets available for all products at

www.scope-uk.com

If any further advice is needed, please call our technical support department on 01803 860720 or email support@scope-uk.com.
